

# HEATER & AIR CONDITIONER

## SECTION **HA**

### CONTENTS

AIR FLOW AND COMPONENT LAYOUT .....	HA- 2
DOOR CONTROL .....	HA- 6
HEATER ELECTRICAL CIRCUIT .....	HA- 9
PRECAUTIONS .....	HA-11
PRECAUTIONS FOR REFRIGERANT CONNECTION .....	HA-12
PREPARATION .....	HA-13
DISCHARGING, EVACUATING, CHARGING AND CHECKING .....	HA-16
SERVICE PROCEDURES .....	HA-22
DESCRIPTION OF AIR CONDITIONER .....	HA-32
A/C PERFORMANCE TEST .....	HA-34
COMPRESSOR OIL — For DKS-16H (DIESEL-KIKI make) .....	HA-41
COMPRESSOR — Model DKS-16H (DIESEL-KIKI make) .....	HA-43
A/C ELECTRICAL CIRCUIT .....	HA-51
A/C ELECTRICAL COMPONENTS .....	HA-54
A/C COMPONENT LAYOUT .....	HA-58
TROUBLE DIAGNOSES .....	HA-60
SERVICE DATA AND SPECIFICATIONS (S.D.S.) .....	HA-77

When you read wiring diagrams:


- Read GI section, "HOW TO READ WIRING DIAGRAMS".
- See EL section, "POWER SUPPLY ROUTING" for power distribution circuit.

**HA**


# AIR FLOW AND COMPONENT LAYOUT

## Air Flow


### FOR L.H. DRIVE MODEL




#### Ventilation




#### Floor




#### Floor and defroster



#### Bi-level



#### Defroster



← : Air passed through heater core

← : Mixed air ( ← + ← )


← : Air not passed through heater core

RHA052A


# AIR FLOW AND COMPONENT LAYOUT

## Air Flow (Cont'd)


### FOR R.H. DRIVE MODEL




#### Floor




#### Ventilation




#### Floor and defroster



#### Bi-level



#### Defroster



- ← : Air passed through heater core
- ← : Mixed air ( ← + ← )
- ← : Air not passed through heater core


RHA053A




## AIR FLOW AND COMPONENT LAYOUT

### Air Flow (Cont'd)

#### OVERHEAD TYPE REAR COOLING UNIT (Type 1)




#### REAR COOLING UNIT (Type 2)



## AIR FLOW AND COMPONENT LAYOUT

### Component Layout



\* For removal, it is necessary to remove instrument assembly.





HA-5

RHA056A

## DOOR CONTROL

### Control Cable and Rod Adjustment

- When adjusting ventilator door rod and defroster door rod, first disconnect air control cable from side link. Reconnect and readjust air control cable.



### VENTILATOR DOOR CONTROL ROD

1. Move side link in direction of arrow.
2. With upper and lower ventilator door levers held in the direction of the arrow as shown in the figure at left, connect rods ① and ② to their corresponding ventilator door levers, in that order.

### DEFROSTER DOOR CONTROL ROD




1. Move side link in direction of arrow.
2. Connect rod to side link while pushing defroster door lever in direction of arrow.

## DOOR CONTROL

### Control Cable and Rod Adjustment (Cont'd)

#### AIR CONTROL CABLE


- Clamp the cable while pushing cable outer and side link in direction of arrow.



#### WATER COCK CONTROL ROD


- When adjusting water cock control rod, first disconnect temperature control cable from air mix door lever. Reconnect and readjust temperature control cable.

1. Push air mix door lever in direction of arrow.
2. Pull control rod of water cock in direction of arrow so as to make clearance of about 2 mm (0.08 in) between ends of rod and link lever and connect the rod to door lever.



#### TEMPERATURE CONTROL CABLE

- Clamp the cable while pushing cable outer and air mix door lever in direction of arrow.







## DOOR CONTROL

### Control Cable and Rod Adjustment (Cont'd)

#### INTAKE DOOR CONTROL CABLE


- Clamp the cable while pushing cable outer and intake door lever in direction of arrow.






# HEATER ELECTRICAL CIRCUIT


## Schematic



## Wiring Diagram



## HEATER ELECTRICAL CIRCUIT




### Inspection

#### FRONT BLOWER MOTOR


Confirm smooth rotation of the blower motor.

- Ensure that there are no foreign particles inside the intake unit.
- If the blower does not rotate, refer to TROUBLE-SHOOTING PROCEDURE 2.



#### FRONT BLOWER RESISTOR

Check continuity between terminals.




#### FRONT FAN SWITCH

Check continuity between terminals at each lever position shown in the table.


##### L.H. drive model

Lever position	OFF	1	2	3	4
Terminal					
31					○
28		○			○
29		○	○		○
30		○	○	○	○
109		○	○	○	○
13		○	○	○	○
110		○	○	○	○
33		○	○	○	○



##### R.H. drive model

Lever position	OFF	1	2	3	4
Terminal					
31					○
28		○			○
29		○	○		○
30		○	○	○	○
109		○	○	○	○
13		○	○	○	○
110		○	○	○	○
33		○	○	○	○




## PRECAUTIONS

### WARNING:

- Always wear eye protection when working around the system.
- Always be careful that refrigerant does not come in contact with your skin.
- Keep refrigerant containers stored below 40°C (104°F) and never drop from high places.
- Work in well-ventilated area because refrigerant gas evaporates quickly and breathing may become difficult due to the lack of oxygen.
- Keep refrigerant away from open flames because poisonous gas will be produced if it burns.
- Do not increase can temperature beyond 40°C (104°F) in charging.
- Do not heat refrigerant can with an open flame. There is danger that can will explode.





### CAUTION

- Do not use steam to clean surface of condenser or evaporator. Be sure to use cold water or compressed air.
- Compressed air must never be used to clean a dirty line. Clean with refrigerant gas.



- Do not use manifold gauge whose press point shape is different from that shown. Otherwise, insufficient evacuating may occur.
- Do not over-tighten service valve cap.
- Do not allow refrigerant to rush out. Otherwise, compressor oil will be discharged along with refrigerant.

## PRECAUTIONS FOR REFRIGERANT CONNECTION



### WARNING:

Gradually loosen discharge side hose fitting, and remove it after remaining pressure has been released.

### CAUTION:

When replacing or cleaning refrigerant cycle components, observe the following.

- Do not leave compressor on its side or upside down for more than 10 minutes, as compressor oil will enter low pressure chamber.
- When connecting tubes, always use a torque wrench.

- After disconnecting tubes, plug all openings immediately to prevent entrance of dirt and moisture.

- Always replace used O-rings.
- When connecting tube, apply compressor oil to portions shown in illustration. Be careful not to apply oil to threaded portion.
- O-ring must be closely attached to inflated portion of tube.

- After inserting tube into union until O-ring is no longer visible, tighten nut to specified torque.
- After connecting line, conduct leak test and make sure that there is no leakage from connections. When the gas leaking point is found, disconnect that line and replace the O-ring. Then tighten connections of seal seat to the specified torque.










## PREPARATION

### SPECIAL SERVICE TOOLS



**DKS-16H model**

\*: Special tool or commercial equivalent

Tool number Tool name	Description
KV99232022 Clutch disc puller	 <p>Removing clutch disc</p>
KV99235140 Shaft seal remover and installer	 <p>Removing and installing shaft seal.</p>
KV99241420 Blind cover set ① KV99241400 ② KV99211100 ③ KV99211300	 <p>Blind cover</p>
KV994C1552 Charge nozzle	 <p>Using charge refrigerant</p>
KV99231010* Clutch disc wrench	 <p>Removing shaft nut and clutch disc</p>
KV99233040* Puller pilot	 <p>Removing pulley</p>
KV99234160* Pulley installer	 <p>Installing pulley</p>







## PREPARATION

\*: Special tool or commercial equivalent

Tool number Tool name	Description
KV99267420* Shaft seal guide	 Installing shaft seal
KV99235160* Nut wrench	 Removing lock nut


## PREPARATION

### SERVICE TOOLS


Tool name	Description
Manifold gauge	 <p>Using discharge and charge refrigerant into system</p>
Charging hose	 <p>Using discharge and evacuate, charge refrigerant into system</p>
Charge valve	 <p>Using discharge and charge refrigerant into system</p>
Thermometer	 <p>Using check temperature</p>
Vacuum pump	 <p>Using evacuate refrigerant system</p>
Electric leak-detector	<p>Nominal sensitivity: 15 - 25 g (0.53 - 0.88 oz)/year</p>  <p>Using check refrigerant leaks</p>

## DISCHARGING, EVACUATING, CHARGING AND CHECKING


---



Discharge refrigerant system.




Run pump for 5 minutes.




Charge refrigerant into system.

When low-pressure gauge reading is 98 kPa (0.98 bar, 1.0 kg/cm<sup>2</sup>, 14 psi), completely close high-pressure valve of manifold gauge and stop charging.




Run pump for 20 minutes.



Charge the specified amount of refrigerant into system.



## DISCHARGING, EVACUATING, CHARGING AND CHECKING



### Discharging—Point-1


Slowly open the valves to discharge only refrigerant. If they are opened quickly, compressor oil will also be discharged.

#### CAUTION:

#### Rear cooler equipped model

On rear cooler equipped model, do the following procedures.

- Ignition switch "ON"
- Front fan switch "ON"
- Front A/C and rear cooler switches "ON"
- Rear cooler temp. switch "Max. COLD"




### Evacuating the System—Point-2

Refer to "CAUTION: Rear cooler equipped model".

1. Start pump, then open both valves and run pump for about 5 minutes.
2. When low gauge has reached approx. 101.3 kPa (1,013 mbar, 760 mmHg, 29.92 inHg), completely close both valves of gauge and stop vacuum pump. Let it stand for 5 to 10 minutes in this state and confirm that the reading does not rise.
  - a. The low-pressure gauge reads lower by 3.3 kPa (33 mbar, 25 mmHg, 0.98 inHg) per 300 m (1,000 ft) elevation. Perform evacuation according to the following table.
  - b. The rate ascension of the low-pressure gauge should be less than 3.3 kPa (33 mbar, 25 mmHg, 0.98 inHg) in 5 minutes.

Elevation m (ft)	Vacuum of system* kPa (mbar, mmHg, inHg)
0 (0)	101.3 (1,013, 760, 29.92)
300 (1,000)	98.0 (980, 735, 28.94)
600 (2,000)	94.6 (946, 710, 27.95)
900 (3,000)	91.3 (913, 685, 26.97)

\*: Values show reading of the low-pressure gauge.




### Charging—Point-3

1. Evacuate refrigerant system.

Refer to "Point-2"

2. Close manifold gauge valves securely and disconnect charging hose from vacuum pump.
3. Purge air from center charging hose.
  - 1) Connect center charging hose to refrigerant can through charge valve.
  - 2) Break seal of refrigerant can and purge air.

## DISCHARGING, EVACUATING, CHARGING AND CHECKING




### Charging—Point-3 (Cont'd)

4. Charge refrigerant into system.

#### WARNING:

Ensure that engine is off.


- 1) Open high-pressure valve of manifold gauge and charge refrigerant into system.



#### CAUTION:

If charging liquefied refrigerant into the system with the can turned upside down to reduce charging time, charge it only through high-pressure (discharge) service valve. After charging, the compressor should always be turned several times manually.


- 2) When low-pressure gauge reading is 98 kPa (0.98 bar, 1.0 kg/cm<sup>2</sup>, 14 psi), completely close high-pressure valve of manifold gauge and stop charging.



### Evacuating the System—Point-4

Refer to "CAUTION: Rear cooler equipped model".

1. Close manifold gauge valve securely and disconnect charging hose from refrigerant can.
2. Connect center charging hose to vacuum pump.
3. Start pump, then open both valves and run pump for about 20 minutes.



### Charging—Point-5

Perform "Point-3 (No. 2—)".

Refer to "CAUTION: Rear cooler equipped model".

1. Charge refrigerant into system.

#### WARNING:

Ensure that engine is off.

- 1) Open low-pressure valve of manifold gauge and charge refrigerant into system.
2. When refrigerant charging speed slows down, close high-pressure valve of manifold gauge and open low-pressure valve of manifold gauge and charge it while running the compressor for ease of charging.
3. Start engine — Air conditioning system ON, maximum temperature set, maximum blower speed. Open low-pressure valve on gauge set, with can in upright position, and monitor sight glass. Charge is complete when sight glass is clear.

Cycling clutch systems will produce bubbles in sight glass when clutch engages. Therefore, allow 5 seconds after clutch engages to determine if bubbles continue, and, if so, add refrigerant to clear sight glass.


## DISCHARGING, EVACUATING, CHARGING AND CHECKING

### Charging—**Point-5** (Cont'd)

#### WARNING:

Never charge refrigerant through high-pressure side (discharge side) of system since this will force refrigerant back into refrigerant can and can may explode.

4. Charge refrigerant while controlling low-pressure gauge reading at 275 kPa (2.75 bar, 2.8 kg/cm<sup>2</sup>, 40 psi) or less by turning in or out low-pressure valve of manifold gauge.
  - Be sure to purge air from charging hose when replacing can with a new one.



5. Charge the specified amount of refrigerant into system by weighing charged refrigerant with scale. Overcharging will cause discharge pressure to rise.

#### Refrigerant amount:

##### Front A/C

0.9 - 1.1 kg (2.0 - 2.4 lb)

##### Front A/C & overhead type rear cooler (Type 1)

1.3 - 1.5 kg (2.9 - 3.3 lb)

##### Front A/C & rear cooler (Type 2)

1.1 - 1.3 kg (2.4 - 2.9 lb)

The state of the bubbles in sight glass should only be used for checking whether the amount of charged refrigerant is small or not. The amount of charged refrigerant can be correctly judged by means of discharge pressure.




6. After charging, be sure to install valve cap on service valve.
7. Confirm that there are no leaks in system by checking with a leak detector.
  - When refrigerant charging is performed with a charging cylinder, charging station, or automatic charging equipment, engine off, charge only through high side, after specified refrigerant amount has entered the system, close high-pressure valve on gauge set. Start engine return to idle speed, operate A/C at maximum temperature setting, high blower. Observe sight glass to confirm complete charge.

Overcharging will result in increased high pressures, and reduced performance.

## DISCHARGING, EVACUATING, CHARGING AND CHECKING

### Checking Refrigerant Level CONDITION

- Door window: Open
- A/C switch: ON
- Rear cooler switch  
(Rear cooler equipped model): ON
- TEMP. lever position: Max. COLD
- Rear cooler temp. switch  
(Rear cooler equipped model): Max. COLD
- FAN lever position: 4
- Rear cooler fan switch  
(Rear cooler equipped model): HI
- Check sight glass after a lapse of about five minutes.

Amount of refrigerant	Almost no refrigerant	Insufficient	Suitable	Too much refrigerant
Check item				
Temperature of high-pressure and low-pressure lines.	Almost no difference between high-pressure and low-pressure side temperature.	High-pressure side is warm and low-pressure side is fairly cold.	High-pressure side is hot and low-pressure side is cold.	High-pressure side is abnormally hot.
State in sight glass.	Bubbles flow continuously. Bubbles will disappear and something like mist will flow when refrigerant is nearly gone.  AC256	The bubbles are seen at intervals of 1 - 2 seconds.  AC257	Almost transparent. Bubbles may appear when engine speed is raised and lowered.  No clear difference exists between these two conditions.  AC258	No bubbles can be seen.
Pressure of system.	High-pressure side is abnormally low.	Both pressures on high and low-pressure sides are slightly low.	Both pressures on high and low-pressure sides are normal.	Both pressures on high and low-pressure sides are abnormally high.
Repair.	Stop compressor immediately and conduct an overall check.	Check for gas leakage, repair as required, replenish and charge system.		Discharge refrigerant from service valve of low pressure side.

a. The bubbles seen through the sight glass are influenced by the ambient temperature. Since the bubbles are hard to show up in comparatively low temperatures below 20°C (68°F), it is possible that a slightly larger amount of refrigerant would be filled, if supplied according to the sight glass. Recheck the amount when it


exceeds 20°C (68°F). In higher temperature the bubbles are easy to show up.

b. When the screen in the receiver drier is clogged, the bubbles will appear even if the amount or refrigerant is normal. In this case, the outlet side pipe of the receiver drier becomes considerably cold.




## DISCHARGING, EVACUATING, CHARGING AND CHECKING

Nominal sensitivity:  
15 - 25 g (0.53 - 0.88 oz)/year




SHA733A

### UNION TYPE



RHA279

### PLATE TYPE



RHA280

## Checking Refrigerant Leaks

### ELECTRIC LEAK DETECTOR

The leak detector is a delicate device that detects small amounts of halogen.

To use the device properly, read the manufacturer's manuals. Also perform the specified maintenance and inspections.

### GENERAL PRECAUTIONS FOR HANDLING LEAK DETECTOR

Place the probe on connection fitting and wait for 5 seconds or more.

To check cooling unit, wait for 10 seconds or more.

#### WARNING:

Keep the probe as still as possible for one more minute.

- When testing single-bolt flange, place the probe on the opposite side of the fitting.


### MEASUREMENT STANDARD

If any leak is noted with a detector having a nominal sensitivity of 15 to 25 g (0.53 to 0.88 oz)/year, that leak must be repaired.

- The nominal sensitivity of the detector is determined under the assumption that all the leaking gas is collected by the detector. Accordingly, the quantity of gas actually leaking can amount to five to ten times the indicated value. Generally speaking, leakage of 150 to 200 g (5.29 to 7.05 oz) of refrigerant can cause insufficient cooling.
- Oil deposited during assembling must be wiped off before inspection. Refrigerant easily dissolves in oil, and the presence of oil can cause an error in measurement. This precaution is important when checking a used car for refrigerant leakage.
- If oil is noted at or around connections, it indicates that refrigerant is leaking.

## SERVICE PROCEDURES

### Refrigeration Cycle



#### REFRIGERANT FLOW

This system has two evaporators; a front evaporator and a rear evaporator. The system design is such that there are the following possibilities for the refrigerant flow path:

- Flow path #1 — through the front evaporator only
- Flow path #2 — through the front and rear evaporators

## SERVICE PROCEDURES

### Refrigeration Cycle (Cont'd)

**Flow path #1** —The front A/C switch is on, the rear cooler switch is off. The rear cooler solenoid valve is closed.

**Flow path #2** —The rear cooler switch is on, the front A/C switch is on. The rear cooler solenoid valve is open.

#### **FREEZE PROTECTION — Compressor control**

The compressor cycles on and off to maintain the front and rear evaporator temperature within a specified range.

The front A/C thermo control amp. controls the compressor clutch (A/C relay) and the rear cooler solenoid valve (rear cooler relay), and the rear cooler thermo control amp. controls the rear cooler solenoid valve (rear cooler relay) according to the following operating conditions:

#### **Front A/C and rear cooler thermo control amp. function**

Operating condition	Function
Front A/C: on Rear cooler: off	The front thermo control amp. disengages the compressor clutch when the front evaporator gets too cold.
Front A/C: on Rear cooler: on	The rear cooler thermo control amp. closes the rear cooler solenoid valve when the rear evaporator gets too cold. The front A/C thermo control amp. disengages the compressor clutch and closes the rear cooler solenoid valve when the front evaporator gets too cold.

The rear evaporator thermo control setting is controlled by the temperature control knob located on the rear cooler control panel, and the front evaporator thermo control setting is pre-set and non-adjustable.

#### **REFRIGERANT SYSTEM PROTECTION**

##### **Dual-pressure switch**

The refrigerant system is protected against excessively high or low pressures by the dual-pressure switch, located on the receiver drier. If the system pressure rises above, or falls below the specifications, the dual-pressure switch opens to interrupt the compressor operation.


##### **Fusible plug**

Open at temperature above 105°C (221°F), thereby discharging refrigerant to the atmosphere. If this plug is melted and opened, check the refrigerant line and replace receiver drier.

## SERVICE PROCEDURES

### Refrigeration Cycle (Cont'd)

#### FRONT A/C L.H. DRIVE MODEL



⌘ : N·m (kg·m, ft·lb)


RHA063A



## SERVICE PROCEDURES

### Refrigeration Cycle (Cont'd)

#### FRONT A/C R.H. DRIVE MODEL




HA-25

RHA066A

## SERVICE PROCEDURES

### Refrigeration Cycle (Cont'd)

#### FRONT A/C & OVERHEAD TYPE REAR COOLER (Type 1) L.H. DRIVE MODEL




RHA065A

## SERVICE PROCEDURES

### Refrigeration Cycle (Cont'd)

#### FRONT A/C & OVERHEAD TYPE REAR COOLER (Type 1) R.H. DRIVE MODEL



⌘ : N·m (kg·m, ft·lb)


RHA283A



## SERVICE PROCEDURES

### Refrigeration Cycle (Cont'd)

#### FRONT A/C & REAR COOLER (Type 2) L.H. DRIVE MODEL




⌘ : N·m (kg-m, ft-lb)

RHA064A

## SERVICE PROCEDURES

### Refrigeration Cycle (Cont'd)

#### FRONT A/C & REAR COOLER (Type 2) R.H. DRIVE MODEL



⌘ : N·m (kg-m, ft-lb)


RHA067A




## SERVICE PROCEDURES

### Compressor Mounting

#### TB engine model



#### TD engine model



## **SERVICE PROCEDURES**

---


### **Belt Tension**

- Refer to MA section.

### **Fast Idle Control Device (F.I.C.D.)**

- For TB engine model, refer to EF & EC section.
- For TD engine model, refer to MA section.

## DESCRIPTION OF AIR CONDITIONER



### A/C Cut System


For Australia A/T models, Gulf standard (Middle East) models, Hardtop and Wagon models with TD engine except for Australia

This system is used to monitor the temperature of coolant for engine. When the engine is heavily overloaded, the compressor is turned off to reduce the overloading by the function of the thermo switch located at radiator.

The thermo switch turns ON when the temperature of coolant for engine increases approx. 107°C (225°F), then A/C cut relay stays in open position to cut power source for compressor.

### Cool Box System — Front


- This system uses cool air from the cooling unit to make it possible to refrigerate.



## DESCRIPTION OF AIR CONDITIONER

### Cool Box System — Rear

- This system uses cool air from the cooling unit to make it possible to refrigerate.



## A/C PERFORMANCE TEST

### Performance Chart

#### TEST CONDITION

Testing must be performed as follows:

Vehicle location: Indoors or in the shade (in a well ventilated place)


Doors: Closed


Door window: Open

Hood: Open

TEMP. lever position: Max. COLD.

Rear cooler temp. switch\*: Max. COLD

Air control lever position:  (Ventilation)

INTAKE lever position:  (Recirculation)

FAN lever and switch\* position: Max. position

Engine speed: 1,500 rpm

Time required before starting testing after air conditioner starts operating: More than 10 minutes

Rear cooler: ON\*

\*: For rear cooler equipped model only

#### TEST READING

##### Single A/C equipped model

##### Recirculating-to-discharge air temperature table

Inside air (Recirculating air) at blower assembly inlet		Discharge air temperature at center ventilator °C (°F)
Relative humidity %	Air temperature °C (°F)	
50 - 60	25 (77)	6.0 - 8.5 (43 - 47)
	30 (86)	11.0 - 14.0 (52 - 57)
	35 (95)	15.5 - 18.5 (60 - 65)
	40 (104)	20.5 - 23.5 (69 - 74)
60 - 70	25 (77)	8.5 - 11.0 (47 - 52)
	30 (86)	14.0 - 17.0 (57 - 63)
	35 (95)	18.5 - 22.0 (65 - 72)
	40 (104)	23.5 - 28.0 (74 - 82)

##### Ambient air temperature-to-compressor pressure table

Ambient air		High-pressure (Discharge side) kPa (bar, kg/cm <sup>2</sup> , psi)	Low-pressure (Suction side) kPa (bar, kg/cm <sup>2</sup> , psi)
Relative humidity %	Air temperature °C (°F)		
50 - 70	25 (77)	981 - 1,226 (9.81 - 12.26, 10.0 - 12.5, 142 - 178)	118 - 196 (1.18 - 1.96, 1.2 - 2.0, 17 - 28)
	30 (86)	1,177 - 1,373 (11.77 - 13.73, 12.0 - 14.0, 171 - 199)	137 - 206 (1.37 - 2.06, 1.4 - 2.1, 20 - 30)
	35 (95)	1,324 - 1,569 (13.24 - 15.69, 13.5 - 16.0, 192 - 228)	157 - 235 (1.57 - 2.35, 1.6 - 2.4, 23 - 34)
	40 (104)	1,520 - 1,765 (15.20 - 17.65, 15.5 - 18.0, 220 - 256)	196 - 275 (1.96 - 2.75, 2.0 - 2.8, 28 - 40)



## A/C PERFORMANCE TEST

### Performance Chart (Cont'd)

#### Overhead type rear cooler (Type 1) equipped model

Recirculating-to-discharge air temperature table

Inside air (Recirculating air) at blower assembly inlet		Discharge air temperature at center ventilator °C (°F)
Relative humidity %	Air temperature °C (°F)	
50 - 60	25 (77)	9.0 - 11.5 (48 - 53)
	30 (86)	13.5 - 16.0 (56 - 61)
	35 (95)	18.0 - 20.0 (64 - 68)
	40 (104)	22.0 - 24.5 (72 - 76)
60 - 70	25 (77)	11.5 - 13.5 (53 - 56)
	30 (88)	16.0 - 18.0 (61 - 64)
	35 (95)	20.0 - 22.5 (68 - 73)
	40 (104)	24.5 - 27.0 (76 - 81)

Ambient air temperature-to-compressor pressure table

Ambient air		High-pressure (Discharge side) kPa (bar, kg/cm <sup>2</sup> , psi)	Low-pressure (Suction side) kPa (bar, kg/cm <sup>2</sup> , psi)
Relative humidity %	Air temperature °C (°F)		
50 - 70	25 (77)	1,373 - 1,520 (13.73 - 15.20, 14.0 - 15.5, 199 - 220)	167 - 226 (1.67 - 2.26, 1.7 - 2.3, 24 - 33)
	30 (86)	1,569 - 1,716 (15.69 - 17.16, 16.0 - 17.5, 228 - 249)	216 - 265 (2.16 - 2.65, 2.2 - 2.7, 31 - 38)
	35 (95)	1,814 - 1,961 (18.14 - 19.61, 18.5 - 20.0, 263 - 284)	245 - 314 (2.45 - 3.14, 2.5 - 3.2, 36 - 46)
	40 (104)	2,059 - 2,354 (20.59 - 23.54, 21.0 - 24.0, 299 - 341)	294 - 373 (2.94 - 3.73, 3.0 - 3.8, 43 - 54)

## A/C PERFORMANCE TEST

### Performance Chart (Cont'd)

#### Rear cooler (Type 2) equipped model

##### Recirculating-to-discharge air temperature table

Inside air (Recirculating air) at blower assembly inlet		Discharge air temperature at center ventilator °C (°F)
Relative humidity %	Air temperature °C (°F)	
50 - 60	25 (77)	7.0 - 9.0 (45 - 48)
	30 (86)	11.5 - 14.0 (53 - 57)
	35 (95)	16.0 - 18.5 (61 - 65)
	40 (104)	20.5 - 23.0 (69 - 73)
60 - 70	25 (77)	9.0 - 12.0 (48 - 54)
	30 (86)	14.0 - 16.5 (57 - 62)
	35 (95)	18.5 - 21.0 (65 - 70)
	40 (104)	23.0 - 25.5 (73 - 78)

##### Ambient air temperature-to-compressor pressure table

Ambient air		High-pressure (Discharge side) kPa (bar, kg/cm <sup>2</sup> , psi)	Low-pressure (Suction side) kPa (bar, kg/cm <sup>2</sup> , psi)
Relative humidity %	Air temperature °C (°F)		
50 - 70	25 (77)	1,177 - 1,324 (11.77 - 13.24, 12.0 - 13.5, 171 - 192)	167 - 226 (1.67 - 2.26, 1.7 - 2.3, 24 - 33)
	30 (86)	1,422 - 1,569 (14.22 - 15.69, 14.5 - 16.0, 206 - 228)	216 - 275 (2.16 - 2.75, 2.2 - 2.8, 31 - 40)
	35 (95)	1,618 - 1,765 (16.18 - 17.65, 16.5 - 18.0, 235 - 256)	255 - 314 (2.55 - 3.14, 2.6 - 3.2, 37 - 46)
	40 (104)	1,863 - 2,059 (18.63 - 20.59, 19.0 - 21.0, 270 - 299)	304 - 363 (3.04 - 3.63, 3.1 - 3.7, 44 - 53)




## A/C PERFORMANCE TEST

### Performance Test Diagnoses

Characteristics revealed by the manifold gauge readings for the air conditioning system are shown in the following.





For how to do the performance test, refer to the item "Performance Chart".

In the following table, the portion smeared with ink on each gauge scale indicates the range showing that the air conditioning system is in good order. This range is described in Performance Chart.

Condition	Probable cause	Corrective action
<b>INSUFFICIENT REFRIGERANT CHARGE</b>   AC352A	<p>Insufficient cooling. Bubbles appear in sight glass.</p> <p>Refrigerant is low, or leaking slightly.</p>	<ol style="list-style-type: none"> <li>1. Leak test.</li> <li>2. Repair leak.</li> <li>3. Charge system.</li> </ol> <p>Evacuate, as necessary, and recharge system.</p>
<b>ALMOST NO REFRIGERANT</b>   AC353A	<p>No cooling action. A lot of bubbles or something like mist appears in sight glass.</p> <p>Serious refrigerant leak.</p>	<p>Stop compressor immediately.</p> <ol style="list-style-type: none"> <li>1. Leak test.</li> <li>2. Discharge system.</li> <li>3. Repair leak(s).</li> <li>4. Replace receiver drier if necessary.</li> <li>5. Check oil level.</li> <li>6. Evacuate and recharge system.</li> </ol>
<b>FAULTY EXPANSION VALVE</b>   AC354A	<p>Slight cooling. Sweat or frosting on expansion valve inlet.</p> <p>Expansion valve restricts refrigerant flow.</p> <ul style="list-style-type: none"> <li>• Expansion valve is clogged.</li> <li>• Expansion valve is inoperative. <ul style="list-style-type: none"> <li>Valve stuck closed.</li> <li>Thermal bulb has lost charge.</li> </ul> </li> </ul>	<p>If valve inlet reveals sweat or frost:</p> <ol style="list-style-type: none"> <li>1. Discharge system.</li> <li>2. Remove valve and clean it. Replace it if necessary.</li> <li>3. Evacuate system.</li> <li>4. Charge system.</li> </ol> <p>If valve does not operate:</p> <ol style="list-style-type: none"> <li>1. Discharge system.</li> <li>2. Replace valve.</li> <li>3. Evacuate and charge system.</li> </ol>




## A/C PERFORMANCE TEST

### Performance Test Diagnoses (Cont'd)

Condition	Probable cause	Corrective action
 <p>AC355A</p>	<p>Insufficient cooling. Sweat on suction line.</p>	<p>Expansion valve allows too much refrigerant through evaporator.</p> <p>Check valve for operation. If suction side does not show a pressure decrease, replace valve.</p>
 <p>AC356A</p>	<p>No cooling. Sweat or frosting on suction line.</p>	<p>Faulty expansion valve.</p> <ol style="list-style-type: none"> <li>1. Discharge system.</li> <li>2. Replace valve.</li> <li>3. Evacuate and replace system.</li> </ol>
<b>AIR IN SYSTEM</b>		
 <p>AC359A</p>	<p>Insufficient cooling. Sight glass shows occasional bubbles.</p>	<p>Air mixed with refrigerant in system.</p> <ol style="list-style-type: none"> <li>1. Discharge system.</li> <li>2. Replace receiver drier.</li> <li>3. Evacuate and charge system.</li> </ol>
<b>MOISTURE IN SYSTEM</b>		
 <p>AC360A</p>	<p>After short operation, suction side may show vacuum pressure reading. During this condition, discharge air will be warm. As a warning of this, reading vibrates around 39 kPa (0.39 bar, 0.4 kg/cm<sup>2</sup>, 6 psi).</p>	<p>Drier is saturated with moisture. Moisture has frozen in expansion valve. Refrigerant flow is restricted.</p> <ol style="list-style-type: none"> <li>1. Discharge system.</li> <li>2. Replace receiver drier (twice if necessary).</li> <li>3. Evacuate system completely. (Repeat 30-minutes evacuating three times.)</li> <li>4. Recharge system.</li> </ol>

## A/C PERFORMANCE TEST


### Performance Test Diagnoses (Cont'd)

Condition	Probable cause	Corrective action
<div data-bbox="145 342 424 387" style="border: 1px solid black; padding: 2px; margin-bottom: 10px;"><b>FAULTY CONDENSER</b></div> <div data-bbox="172 544 467 880">  </div> <div data-bbox="443 947 523 969" style="text-align: right; font-size: small;">AC361A</div>	<p>No cooling action: engine may overheat. Bubbles appear in sight glass of drier. Suction line is very hot.</p>	<p>Usually a malfunctioning condenser.</p> <ul style="list-style-type: none"> <li>● Check fan belt and fluid coupling</li> <li>● Check condenser for dirt accumulation.</li> <li>● Check engine cooling system for overheating.</li> <li>● Check for refrigerant overcharging.</li> </ul> <p>If pressure remains high in spite of all above actions taken, remove and inspect the condenser for possible oil clogging.</p>
<div data-bbox="145 1014 568 1059" style="border: 1px solid black; padding: 2px; margin-bottom: 10px;"><b>HIGH PRESSURE LINE BLOCKED</b></div> <div data-bbox="188 1070 483 1406">  </div> <div data-bbox="451 1417 531 1440" style="text-align: right; font-size: small;">AC362A</div>	<p>Insufficient cooling. Frosted high pressure liquid line.</p>	<p>Drier clogged, or restriction in high pressure line.</p> <ol style="list-style-type: none"> <li>1. Discharge system.</li> <li>2. Remove receiver drier or strainer and replace it.</li> <li>3. Evacuate and charge system.</li> </ol>
<div data-bbox="145 1462 448 1507" style="border: 1px solid black; padding: 2px; margin-bottom: 10px;"><b>FAULTY COMPRESSOR</b></div> <div data-bbox="188 1541 483 1877">  </div> <div data-bbox="451 1888 531 1910" style="text-align: right; font-size: small;">AC363A</div>	<p>Insufficient cooling.</p>	<p>Internal problem in compressor, or damaged gasket and valve.</p> <ol style="list-style-type: none"> <li>1. Discharge system.</li> <li>2. Remove and check compressor.</li> <li>3. Repair or replace compressor.</li> <li>4. Check oil level.</li> <li>5. Replace receiver drier.</li> <li>6. Evacuate and charge system.</li> </ol>



## A/C PERFORMANCE TEST

### Performance Test Diagnoses (Cont'd)

Condition	Probable cause	Corrective action
<div data-bbox="135 331 391 405" style="border: 1px solid black; padding: 2px; width: fit-content;"> <b>TOO MUCH OIL IN SYSTEM (Excessive)</b> </div> <div data-bbox="156 483 451 819" style="text-align: center;">  </div> <div data-bbox="421 824 504 846" style="text-align: right; font-size: small;">AC364A</div>	<p>Insufficient cooling.</p>	<p>Too much oil circulates with refrigerant, causing the cooling capacity of the system to be reduced.</p> <p>Refer to COMPRESSOR OIL for correcting oil level.</p>

## COMPRESSOR OIL — For DKS-16H (DIESEL-KIKI make)

### Checking and Adjusting

The oil used to lubricate the compressor is circulating with the refrigerant.

Whenever replacing any component of the system or a large amount of gas leakage occurs, add oil to maintain the original amount of oil.

#### OIL CAPACITY

Unit: mL (Imp fl oz)

Applied model	Without rear cooler model	With rear cooler model
Capacity		
Total in system	200 (7.0)	250 (8.8)
Amount of oil which can be drained	110 (3.9)*	
Compressor (Service parts) charging amount	200 (7.0)	

\*: All oil cannot be drained from system.

#### OIL RETURN OPERATION

Before checking and adjusting oil level, operate compressor at engine idling speed, with controls set for maximum cooling and high blower speed, for 20 to 30 minutes in order to return oil to compressor.

#### CHECKING AND ADJUSTING FOR USED COMPRESSOR

1. After oil return operation, stop the engine and discharge refrigerant and then remove compressor from the vehicle.
2. Remove oil drain plug, drain compressor oil from compressor oil sump and measure the amount.

Oil is sometimes hard to extract when compressor is cooled. Remove oil while compressor is warm [maintained to 40 to 50°C (104 to 122°F)].

3. If the amount is less than 110 mL (3.9 Imp fl oz), some refrigerant may have leaked out. Conduct leak tests on connections of each system, and if necessary, repair or replace faulty parts.

4. Check the purity of the oil and then adjust oil level following the procedure below.

(a) When oil is clean;

Unit: mL (Imp fl oz)

Amount of oil drained	Adjusting procedure
Above 110 (3.9)*	Oil level is right. Pour in same amount of oil as was drained out.
Below 110 (3.9)	Oil level may be low. Pour in 110 mL (3.9 Imp fl oz) of oil.

\*: If amount of oil drained is much greater than under normal circumstances, flush air conditioner system with refrigerant. Then pour in 200 mL (7.0 Imp fl oz) of oil into air conditioner system.

- (b) When oil contains chips or foreign material;  
After air conditioner system has been flushed with refrigerant, replace receiver drier. Then pour in 200 mL (7.0 Imp fl oz) of oil into air conditioner system.

#### CHECKING AND ADJUSTING FOR COMPRESSOR REPLACEMENT

200 mL (7.0 Imp fl oz) of oil is charged in compressor (service parts). So it is necessary to drain the proper amount of oil from new compressor. Follow the procedure below.

1. After oil return operation, drain compressor oil from used compressor and measure the amount.  
(It is the same procedure as CHECKING AND ADJUSTING FOR USED COMPRESSOR.)

## COMPRESSOR OIL — For DKS-16H (DIESEL-KIKI make)

### Checking and Adjusting (Cont'd)

2. Check the purity of the oil and then adjust oil level following the procedure below.

(a) Oil is clean;

Unit: mL (Imp fl oz)

Amount of oil drained from used compressor	Draining amount of oil from new compressor
Above 110 (3.9)*	$200 (7.0) - [\text{Amount of oil drained} + 25 (0.9)]$
Below 110 (3.9)	110 (3.9)

\*: If amount of oil drained is much greater than under normal circumstances, flush air conditioner system with refrigerant. Then install new compressor [200 mL (7.0 Imp fl oz) of oil is changed compressor service parts.]

Example:

Unit: mL (Imp fl oz)


Amount of oil drained from used compressor	Draining amount of oil from new compressor
135 (4.8)	90 (3.2)
95 (3.3)	110 (3.9)

- (b) When oil contains chips or foreign material;  
After air conditioner system has been flushed with refrigerant, replace receiver drier. Then install new compressor. [200 mL (7.0 Imp fl oz) of oil is charged in compressor service parts.]

### **Precautions**

- Plug all openings to prevent moisture and foreign matter from entering.
- Do not leave compressor on its side or upside down for more than 10 minutes.
- When replacing or repairing compressor, check compressor oil level in system.
- When replacing with a new compressor, drain specified oil from new compressor. Refer to COMPRESSOR OIL.
- Be sure there is no oil or dirt on frictional surface of clutch disc and pulley.
- When replacing compressor clutch, be careful not to scratch shaft or bend pulley.
- When replacing compressor clutch assembly, do not forget BREAK-IN OPERATION.
- When storing a compressor, be sure to fill it with refrigerant to prevent rust formation. Add refrigerant at the low-pressure side and purge air at the high-pressure side, while rotating shaft by hand.
  
- Replace shaft seal, seal seat, oil seal and O-ring as a set.
- When installing shaft seal, seal seat, oil seal, O-ring and gaskets, apply compressor oil sparingly to the contact surface. Do not reuse them.
- After replacement or repairs, conduct a Leak Test.

# COMPRESSOR — Model DKS-16H (DIESEL-KIKI make)







⊗ : N·m (kg·m, ft·lb)

SHA908B



## COMPRESSOR — Model DKS-16H (DIESEL-KIKI make)



### Compressor Clutch

#### REMOVAL

- When removing shaft nut, hold clutch disc with clutch disc wrench.

- Using clutch disc puller, clutch disc can be removed easily.

- Bend down pawl of lock washer.
- When removing pulley, remove lock nut with nut wrench.

- Remove the pulley by hand. If difficult, use pulley pilot.

#### INSPECTION

##### Clutch disc

If the contact surface shows signs of damage due to excessive heat, the drive plate and pulley should be replaced.






##### Pulley

Check the appearance of the pulley assembly. If the contact surface of the pulley shows signs of excessive grooving due to slippage, both the pulley and drive plate should be replaced. The contact surfaces of the pulley assembly should be cleaned with a suitable solvent before reinstallation.

##### Coil

Check coil for loose connection or cracked insulation.

## COMPRESSOR — Model DKS-16H (DIESEL-KIKI make)



### Compressor Clutch

#### REMOVAL

- When removing shaft nut, hold clutch disc with clutch disc wrench.

- Using clutch disc puller, clutch disc can be removed easily.

- Bend down pawl of lock washer.
- When removing pulley, remove lock nut with nut wrench.

- Remove the pulley by hand. If difficult, use pulley pilot.

#### INSPECTION

##### Clutch disc

If the contact surface shows signs of damage due to excessive heat, the drive plate and pulley should be replaced.






##### Pulley

Check the appearance of the pulley assembly. If the contact surface of the pulley shows signs of excessive grooving due to slippage, both the pulley and drive plate should be replaced. The contact surfaces of the pulley assembly should be cleaned with a suitable solvent before reinstallation.

##### Coil

Check coil for loose connection or cracked insulation.

## COMPRESSOR — Model DKS-16H (DIESEL-KIKI make)



### Compressor Clutch

#### REMOVAL

- When removing shaft nut, hold clutch disc with clutch disc wrench.

- Using clutch disc puller, clutch disc can be removed easily.

- Bend down pawl of lock washer.
- When removing pulley, remove lock nut with nut wrench.

- Remove the pulley by hand. If difficult, use pulley pilot.

#### INSPECTION

##### Clutch disc

If the contact surface shows signs of damage due to excessive heat, the drive plate and pulley should be replaced.

##### Pulley

Check the appearance of the pulley assembly. If the contact surface of the pulley shows signs of excessive grooving due to slippage, both the pulley and drive plate should be replaced. The contact surfaces of the pulley assembly should be cleaned with a suitable solvent before reinstallation.

##### Coil




Check coil for loose connection or cracked insulation.

## COMPRESSOR — Model DKS-16H (DIESEL-KIKI make)

### Compressor Clutch (Cont'd)

#### INSTALLATION

- Install the key in the keyway on the compressor drive shaft.
- Install the coil to compressor (lead wire up) and tighten the mounting screws.
- Install the lead wire with its holder into the hold.



- Install lock washer and nut with nut wrench.
- Bend one pawl of the lock washer up against the nut to prevent the nut from loosening.

- Check to ensure that the clutch clearance is between 0.3 to 0.6 mm (0.012 to 0.024 in). Adjust the clearance using shim(s) as necessary.

#### BREAK-IN OPERATION

When replacing compressor clutch assembly, do not forget break-in operation, accomplished by engaging and disengaging the clutch about thirty times.


Break-in operation raises the level of transmitted torque.

### Shaft Seal Assembly

The shaft seal assembly is a precision-part, with it's critical parts finished to extremely close tolerances and, as such, must be handled with great care. Its slip face demands particularly careful handling.


#### REMOVAL

- Remove the magnetic clutch assembly, as outlined in "Compressor Clutch-REMOVAL".
- Using Internal Snap Ring Pliers, remove the seal seat/compressor snap ring.
- Remove and discard seal seat.
- Using a suitable piece of wire, remove the O-ring from the inside groove of the shaft seal housing. Discard the O-ring.






## COMPRESSOR — Model DKS-16H (DIESEL-KIKI make)




### Shaft Seal Assembly (Cont'd)

- Remove the shaft seal as follows. Turning clockwise, engage the remover hook with the shaft seal hook, and slowly draw out the seal. Discard the shaft seal.
- Check the shaft and inside of the compressor neck for dirt of foreign material and ensure these areas are perfectly clean before installing new shaft seal.




### INSPECTION

- Shaft seal assembly should not be reused. Always use a new shaft seal kit on reassembling the compressor. Be extremely careful to ensure that the face of the shaft of the shaft seal to be installed is not scratched or damaged in anyway. Make sure the seal seat and shaft seal are free of lint and dirt that could damage the shaft seal surface.



### INSTALLATION


Clean the sealed section of the compressor. Apply clean compressor oil to the new shaft seal and the drive shaft. If the slip faces are dirty, clean them with thinners and after drying the cleaned faces, apply clean compressor oil. Fit the new O-ring with clean compressor oil to the groove inside the compressor neck. Apply clean compressor oil to the seal seat.



### Cylinder Heads (Front & Rear)





#### DISASSEMBLY

- Remove the compressor clutch assembly, as outlined in "Compressor Clutch-REMOVAL".
- Remove the oil filler plug and drain plug, and then draw out the oil.
- Remove the shaft seal assembly, as outlined in "Shaft Seal Assembly-REMOVAL".
- Remove the felt, stopper and six through-bolts securing the head, using a wrench.
- Alternately tap four projections on the circumference of the front head with a screwdriver and a plastic mallet, and remove the front cylinder head.





## COMPRESSOR — Model DKS-16H (DIESEL-KIKI make)



### Cylinder Heads (Front & Rear)(Cont'd)

- Remove and discard the O-ring from the front cylinder head.
- Remove all gasket material from the front cylinder head and front valve plate.

- Alternately tap four projections on the circumference of the rear head with a screwdriver and a plastic mallet, and remove the rear cylinder head.

- Remove the gear pump from the rear cylinder head or drive shaft end. Remove all gasket material from the rear cylinder head and rear valve plate. Remove and discard the O-ring from the rear side of the cylinder shaft assembly.


### INSPECTION

Check the front and rear valve plates for scratched, bent or otherwise damaged parts. Inspect both cylinder heads and both valve plate assemblies for nicks or burrs on the sealing surfaces. Clean, or replace if badly damaged. Make sure that all passages in the valve plate are unobstructed. If either the cylinder head or valve plate is cracked, it must be replaced.

### INSTALLATION

- Installation is the reverse of removal.
- Tighten bolts or plugs to specified torques.

## COMPRESSOR — Model DKS-16H (DIESEL-KIKI make)



### Leak Test

- Charge refrigerant from suction side and evacuate air from discharge side. Then conduct leak test.

## **COMPRESSOR — Model DKS-16H (DIESEL-KIKI make)**

---

Note:


## Schematic






# A/C ELECTRICAL CIRCUIT

## Wiring Diagram



## A/C ELECTRICAL CIRCUIT


### Wiring Diagram (Cont'd)



- (GC) : A/T model for Gulf standard (Middle East)
- (EG) : Except A/T model for Gulf standard (Middle East)
- (GA) : Except (EA)
- (EA) : For Australia A/T models, Gulf standard models (Middle East), Hard top & Wagon models with TD engine except for Australia
- (WI) : With rear cooler model
- (NO) : Without rear cooler model
- (OH) : Over head cooler model (Type 1)
- (EX) : Except Over head cooler model (Type 2)
- (R.H.) : R.H. drive model
- (L.H.) : L.H. drive model

SHA043C

## A/C ELECTRICAL COMPONENTS




### Inspection

#### FRONT A/C SWITCH

Check continuity between terminals at each switch position shown in the table.


	ON	OFF
5	○	○
13	○	○
14	○	○



#### FRONT A/C THERMO CONTROL AMP.

1. Run engine, and operate front A/C system.
2. Connect the voltmeter from harness side.
3. Check front A/C thermo control amp. operation shown in the table.


Evaporator outlet air temperature °C (°F)	Thermo amp. operation	Tester
Decreasing to 0.1 - 0.9 (32 - 34)	Turn OFF	Approx. 12V
Increasing to 2.5 - 3.5 (37 - 38)	Turn ON	Approx. 0V



#### DUAL-PRESSURE SWITCH

Check continuity between terminals after disconnecting dual-pressure switch connector.

High-pressure side line pressure kPa (bar, kg/cm <sup>2</sup> , psi)	Operation	Continuity
<ul style="list-style-type: none"> <li>Decreasing to 177 - 216 (1.77 - 2.16, 1.8 - 2.2, 26 - 31)</li> <li>Increasing to 2,452 - 2,844 (24.5 - 28.4, 25 - 29, 356 - 412)</li> </ul>	Turn OFF	Not exist
<ul style="list-style-type: none"> <li>Increasing to 177 - 235 (1.77 - 2.35, 1.8 - 2.4, 26 - 34)</li> <li>Decreasing to 1,863 - 2,256 (18.6 - 22.6, 19 - 23, 270 - 327)</li> </ul>	Turn ON	Exists



#### REAR COOLER SWITCH

Check continuity between terminals at each switch position shown in the table.



	A	B
8	○	○
34	○	○
35	○	○
43	○	○
106	○	○

## A/C ELECTRICAL COMPONENTS

### Inspection (Cont'd)

#### REAR COOLER CONTROL ASSEMBLY

1. Check continuity between terminals at each switch position shown in the table.



2. Check rheostat.

- Confirm smooth rotation of the rear cooler temperature control knob.
- Using an ohmmeter, check the rheostat values.

Terminal	Rear cooler temp. switch		
	OFF	ON	ON: MAX. COLD
⑥1 - ①07	Continuity: Not exist	Approx. 10 $k\Omega$ $\leftrightarrow$ Approx. 0 $\Omega$	






## A/C ELECTRICAL COMPONENTS

### Inspection (Cont'd)

#### REAR COOLER THERMO CONTROL AMP.


1. Start engine, and operate front A/C and rear cooler system.
2. Connect voltmeter from harness side.
3. Check rear cooler thermo control amp. operation shown in the table.

Rear temp. control position	Evaporator outlet air temperature °C (°F)	Operation	Voltage
MAX. COLD	Decreasing to -1.5 to 0.5 (29 - 33)	Turn OFF	Approx. 12V
	Increasing to 2.5 - 4.5 (37 - 40)	Turn ON	Approx. 0V
MAX. HOT	Decreasing to 13.5 - 15.5 (56 - 60)	Turn OFF	Approx. 12V
	Increasing to 6.5 - 20.5 (44 - 69)	Turn ON	Approx. 0V



#### REAR COOLER SOLENOID VALVE


Check continuity between terminals.



#### REAR BLOWER MOTOR

Confirm smooth rotation of the blower motor.

- Ensure that there are no foreign particles inside the blower unit.
- If the blower does not rotate, refer to TROUBLE-SHOOTING PROCEDURE 3.








## A/C ELECTRICAL COMPONENTS

### Inspection (Cont'd)

#### REAR BLOWER RESISTOR

Check continuity between terminals.



#### THERMO SWITCH

For Australia A/T models, Gulf standard (Middle East) models, Hardtop and Wagon models with TD engine except for Australia


Engine coolant temperature °C (°F)	Operation
Increasing to 107 (225)	ON
Decreasing to 103 (217)	OFF

Refer to LC section.




## A/C COMPONENT LAYOUT

### ENGINE COMPARTMENT



TB42 engine model




TD42 engine model




A/C cut relay  
[For Australia A/T models, Gulf standard models  
(Middle East), Hardtop and Wagon models with  
TD engine except for Australia]



TB engine model



TD engine model





RHA080A






## A/C COMPONENT LAYOUT

### PASSENGER COMPARTMENT

#### Overhead type rear cooler (Type 1)



#### Rear cooler (Type 2)





# TROUBLE DIAGNOSES

## Trouble-shooting

### INSPECTION TABLE

No.	INCIDENT	"HOW TO REPAIR"	INSPECTION PORTION															
			10A Fuse *1	15A Fuse*1	20A Fuse*1	Fusible link (Green)*1	Front blower motor	Rear blower motor(s)	Front resistor	Rear resistor	Front A/C switch	Front fan switch	Rear cooler switch	Fan switch	Temp. switch	A/C relay	A/C cut relay*2	Rear cooler relay
1	Magnet clutch does not operate.	Go to TROUBLE-SHOOTING PROCEDURE 1.	○			○					○	○				○	○	
2	Front blower motor does not rotate.	Go to TROUBLE-SHOOTING PROCEDURE 2.		○			○		○			○						
3	Rear blower motor(s) does not rotate.	Go to TROUBLE-SHOOTING PROCEDURE 3.	○		○			○		○		○	○					○
4	Rear cooler solenoid valve does not operate.	Go to TROUBLE-SHOOTING PROCEDURE 4.	○		○						○	○			○	○	○	○

This table indicates the inspection portion for each type of incident.

\*1: For location, refer to PRELIMINARY CHECK.

\*2: For Australia A/T models, Gulf standard models (Middle East), Hardtop and Wagon models with TD engine except for Australia

### PRELIMINARY CHECK

#### Compressor belt tension check

Check compressor belt deflection.


Adjust belt deflection if it exceeds the limit.

Refer to "Checking Drive Belts" in MA section.

#### Power supply circuit check for air conditioning system

Check power supply circuit for air conditioning system.

Refer to "Power Supply Routing" in EL section and A/C ELECTRICAL CIRCUIT.



## TROUBLE DIAGNOSES

### Trouble-shooting (Cont'd)

#### Front A/C thermo control amp. check

Check power supply and body ground circuit for front A/C thermo control amp. with ignition switch ON.

1. Disconnect front A/C thermo control amp. connector.
2. Connect voltmeter from harness side.
3. Measure voltage across terminal No. ⑮ and body ground.

Voltmeter terminal		Voltage
+	-	
⑮	Body ground	Approx. 12V

4. Switch to ignition switch OFF, A/C switch ON and front fan switch ON.
5. Connect ohmmeter from harness side.
6. Check continuity between terminal No. ⑭ and body ground.

Ohmmeter terminal		Continuity
+	-	
⑭	Body ground	Yes

#### Rear cooler thermo control amp. check



Check power supply and body ground circuit for rear cooler thermo control amp. with ignition switch ON, front A/C ON and rear cooler ON.

1. Disconnect rear cooler thermo control amp. connector.
2. Connect voltmeter from harness side.
3. Measure voltage across terminal No. ④⑧ and body ground.

Voltmeter terminal		Voltage
+	-	
④⑧	Body ground	Approx. 12V

4. Switch to ignition switch OFF.
5. Connect ohmmeter from harness side.
6. Check continuity between terminal No. ⑩④ and body ground.

Ohmmeter terminal		Continuity
+	-	
⑩④	Body ground	Yes






# TROUBLE DIAGNOSES

## Trouble-shooting (Cont'd)

### CIRCUIT FOR TROUBLE DIAGNOSES



SHA045C





## TROUBLE DIAGNOSES

### Trouble-shooting (Cont'd)

#### TROUBLE-SHOOTING PROCEDURE 1

**INCIDENT: Magnet clutch does not operate.**

- Perform preliminary check before referring to the following flowchart.



**Note:**




If the result is N.G. after checking circuit continuity, repair harness or connector.

\*1: For Australia A/T models, Gulf standard models (Middle East), Hardtop and Wagon models with TD engine except for Australia

\*2: Except for \*1

## TROUBLE DIAGNOSES






### Trouble-shooting (Cont'd)





## TROUBLE DIAGNOSES

### Trouble-shooting (Cont'd)



**Note:**




If the result is N.G. after checking circuit continuity, repair harness or connector.

\*1: For Australia A/T models, Gulf standard models (Middle East), Hardtop and Wagon models with TD engine except for Australia

\*2: Except for \*1

## TROUBLE DIAGNOSES

### Trouble-shooting (Cont'd)




**Note:**

If the result is N.G. after checking circuit continuity, repair harness or connector.



## TROUBLE DIAGNOSES

### Trouble-shooting (Cont'd)



**Note:**

If the result is N.G. after checking circuit continuity, repair harness or connector.

## TROUBLE DIAGNOSES



	INCIDENT	Flowchart No.
1	Fan fails to rotate.	1
2	Fan does not rotate at 1-speed.	2
3	Fan does not rotate at 2-speed.	3
4	Fan does not rotate at 3-speed.	4
5	Fan does not rotate at 4-speed.	5

### Trouble-shooting (Cont'd)

#### TROUBLE-SHOOTING PROCEDURE 2

**INCIDENT:** Front blower motor does not rotate.

- Perform preliminary check before referring to the following flowchart.



Check if blower motor rotates properly at each fan speed. Conduct checks as per flowchart at left.

**A**

Check power supply for blower motor with ignition switch ON and fan switch OFF.

Do approx. 12 volts exist between blower motor harness terminal No. ④ and body ground?

N.G.

Check 15A fuses at fuse block. (Refer to Preliminary Check.)

O.K.

Disconnect blower motor harness connector.

Check circuit continuity between blower motor harness terminal No. ⑫ and body ground with ignition switch OFF and fan switch ON.

N.G.

Reconnect blower motor harness connector.

O.K.

Replace blower motor.

**B**

Check blower motor circuit between blower motor and resistor with ignition switch ON and fan switch OFF.

Do approx. 12 volts exist between resistor harness terminal No. ⑫ and body ground?

N.G.

Check circuit continuity between blower motor harness terminal No. ⑫ and resistor harness terminal No. ⑫.

O.K.

**A**



Note

**Note:**

If the result is N.G. after checking circuit continuity, repair harness or connector.

## TROUBLE DIAGNOSES

### Trouble-shooting (Cont'd)



**Note:**

If the result is N.G. after checking circuit continuity, repair harness or connector.


## TROUBLE DIAGNOSES

### Trouble-shooting (Cont'd)

#### TROUBLE-SHOOTING PROCEDURE 3

**INCIDENT: Rear blower motor does not rotate.**





- Perform preliminary check before referring to the following flowchart.





## TROUBLE DIAGNOSES

### Trouble-shooting (Cont'd)




**Note:**

If the result is N.G. after checking circuit continuity, repair harness or connector.



## TROUBLE DIAGNOSES

### Trouble-shooting (Cont'd)



**Note:**

If the result is N.G. after checking circuit continuity, repair harness or connector.



## TROUBLE DIAGNOSES

### Trouble-shooting (Cont'd)

#### TROUBLE-SHOOTING PROCEDURE 4

**INCIDENT:** Rear cooler solenoid valve does not operate.

- Perform preliminary check before referring to the following flowchart.







**Note:**

If the result is N.G. after checking circuit continuity, repair harness or connector.

## TROUBLE DIAGNOSES

### Trouble-shooting (Cont'd)







**Note:**

If the result is N.G. after checking circuit continuity, repair harness or connector.

## TROUBLE DIAGNOSES

## Trouble-shooting (Cont'd)






**Note:**  
If the result is N.G. after checking circuit continuity, repair harness or connector.



## TROUBLE DIAGNOSES

### Trouble-shooting (Cont'd)



**Note:**

If the result is N.G. after checking circuit continuity, repair harness or connector.

## SERVICE DATA AND SPECIFICATIONS (S.D.S.)

### General Specifications

#### COMPRESSOR

Model	DIESEL-KIKI make DKS-16H	
Type	Swash plate	
Displacement	cm <sup>3</sup> (cu in)/Rev.	167 (10.19)
Cylinder bore x stroke	mm (in)	37.0 x 25.8 (1.457 x 1.016)
Direction of rotation	Clockwise (Viewed from drive end)	
Drive belt	A type	

#### LUBRICATION OIL

Model	Without rear cooler model	With rear cooler model
	DIESEL-KIKI make DKS-16H	
Type	SUNISO 5GS	
Capacity	ml (Imp fl oz)	
Total in system	200 (7.0)	250 (8.8)
Remaining oil in system after oil return operation and draining it	Approx. 90 (3.2)	Approx. 140 (4.9)
Compressor (Service parts) charging amount	200 (7.0)	

#### REFRIGERANT

Type	R-12
Capacity	kg (lb)
Front A/C	0.9 - 1.1 (2.0 - 2.4)
Front A/C & overhead type rear cooler (Type 1)	1.3 - 1.5 (2.9 - 3.3)
Front A/C & rear cooler (Type 2)	1.1 - 1.3 (2.4 - 2.9)

### Inspection and Adjustment

#### ENGINE IDLING SPEED

- For TB engine model, refer to EF & EC section.
- For TD engine model, refer to MA section.

#### BELT TENSION

- Refer to MA section

#### COMPRESSOR

Model	DKS-16H
Clutch hub to pulley clearance	mm (in)
	0.3 - 0.6 (0.012 - 0.024)